



**SHARKEY
MACHINE
SERVICE**

**Shark Fin Grid-Cap
Installation Summary**

Installation Procedure

1. Lock and tag-out all necessary equipment.
2. Open drains or vat doors.
3. Wash drum with mill water supply.
4. Remove bands and face wire.
5. Remove backing wire.
6. Repair minor grid problems and grind where necessary.
7. Wash down drum again.
- 8. Size Shark-Fin Grid-Caps to proper dimensions**
9. Install Shark-Fin Grid-Caps.
10. Feather Shark-Fin Grid-Caps at end rings.
11. Install face-wire (metal or plastic) and bands.
12. Set Doctor assembly to proper dimensions.
13. Check vat for debris and wash down again.
14. Close drain or vat doors.
- 15. Review installation with mill representative.**
16. Remove all locks and tags.
17. Clean area and put all trash into customer supplied containers.
18. Start on next assigned drum at item #1.

Sharkey Machine Service

FAX: (706) 885-9040
1010 Longley Place
LaGrange, GA 30240

More Questions?

Call Us at:
(706) 885-0905